



1D WIRELESS

Handheld Barcode Scanner
SC305



User's
MANUAL




Introduction

This is a Quick Start manual, for full version please download programming manual from our website at <http://www.3nStar.com> or contact your local provider.

Installation


Connect the base to the computer, place the scanner on the base. When all the leds of the base are ON, the base is ready to receive data. Keep the scanner on the base while is not in use.

USB Connection



Note: Charging the scanner through a USB port takes more time than direct AC adapter charging

Accessories



- 1: the base
- 2: data cable
- 3: AC adapter

Factory Default and Pairing

- 1-Scan Factory Default



- 2- Disconnect and connect the scanner base from the PC.
- 3- While the power and data leds are blinking, scan the following bars:

- Scan RF MODEL



- Scan PAIRED ADD



- 4- Wait for the leds to stop blinking, the scanner now is ready.

Firmware Version



Inventory Mode



Inventory Mode



Up lodaing New Data



Up lodaing All Data



Up loading Statistic Data



Clear

NOTE: to exit inventory mode, scan INVENTORY MODE bars again

Display Barcode Type



Display barcode type after barcode



UN-Display type after barcode

Keyboard Mode

☐ Language Selection



USA



German



France



Spain

☐ Keyboard Caps Lock Control



None



Capitalize



Lower case

☐ Prefix&Suffix Setting



AddPre



AddSuff



Hide Before
Character



Hide After Character

Special Code ON



CODE11



CODE 39



FULL ASCII



CODE 93



CODE 128



CODE 128ISBT



CODEBAR



Enable Interleaved
2 of 5



Industrial 2 of 5



Matrix 2 of 5



CHINA POST CODE



MSI CODE



UPC-A



UPC-E



EAN-13



EAN-8

☐ Suffix & Skip Setting



CR



LF



CR&LF



Tab



Space



None

Scanning Type



Automatic successive
scanning



Automatic flashing

Buzzer



Sound OFF



Sound ON