

LABEL PRINTER LDT060B

**BLUETOOTH
CONNECTION**

**DRIVER AND APP
INSTALLATION GUIDE**



TABLE OF CONTENTS

Windows Bluetooth Driver Installation	4
Android Driver Bluetooth Barcode printer	6
ChromeOS Bluetooth Driver Installation	8
4Barcode Bluetooth Connection Instructions	12
Ezlabel Bluetooth Connection Instructions	14



DISCLAIMER


Please be aware that the transmission interface and appearance of the printer shown in this picture may differ depending on the specific model you have purchased. For precise information regarding the transmission interface and appearance, we advise consulting the actual product or reaching out to your supplier directly.

Windows Bluetooth Driver Installation:


1. Open driver “4BARCODE_202*. *_M-*.exe”.




2. Accept the license and “Next”




3. Choose “Run Driver Wizard after unpacking drivers”, and “Finish”.




4. Choose “Install printer drivers” and “Next”.




5. Choose “Bluetooth” and “Add Device Wizard” to pair the printer.




6. Choose the Bluetooth printer, and “Next”.




- 6A. It will ask for the passcode, the default passcode is “0000”, after input the passcode, click “Next”.




6B. . Then it will back to “Seagull Driver Wizard” window, click “Next”.




7. Choose the Bluetooth printer and click “OK”.




8. Choose the model of your printer, and “Next”.




9. Click “Next” then click “Finish”



9A. Then Click “Finish”



10. Completed.



Android Driver Bluetooth Barcode printer


LABEL PRINTER APP INSTALLATION

Scan the QR code below using an Android device to download the Label Printer App.





ADDING NEW PRINTER


1. Open the app and connect the printer through a USB cable
2. Connect the printer through a USB cable. Open the app and agree on the privacy policy.




3. Tap the icon on the top right to enter the adding new printer page.




4. Give a name for the printer.




7. The setting has been completed, go back to the main page and tap the new printer to establish the connection.




5. Choose the Bluetooth connection method




8. Press the round button to print a test page.



6. Tap the "Device/Address" item, then choose the target printer in the list.




9. The printer will demand pairing for the first time, enter the PIN code (0000) and press OK. Then the printer will start to print a test page.




ChromeOS Bluetooth Driver Installation


1. Open the Google Chrome browser and click "Menu"




2. Click "Extensions" and select "Visit Chrome Web Store"




3. Click "Extensions".




4. Search the "POS & Label Printer Manger" and click it




5. Click "POS & Label Printer Manger".




6. Click "Add to Chrome".




6A. It will ask for Add “POS & Label Printer Manager”?, click “Add extension”.




6B. Then wait for the download completely.




7. Then automatically enter the POS & Label Printer Manager page. Choose “Bluetooth” and Click “Connect”




8. Choose the model name of the printer, as shown “4B-2054N”, and then click “Pair”



9. After successfully connecting to the printer, enter the “Settings” page, and the Command Type select “TSPL”.




10. Then enter the Customer Paper Size and click “Save”. ChromeOS driver installation complete.




Driver Test page

1. Open the “Test” page and click “send”




2. Complete




PDF TEST PAGE

1. Open the PDF and click “Print” icon



2. The Destination select “POS Printer” and check the Quality. Click “Print”.



4Barcode Bluetooth Connection


INSTRUCTIONS

Scan the QR code below using an Android or iOS device to download the 4Barcode APP.




4Barcode


1. Open “4Barcode” APP, tap the printer icon in the top right corner to connect the printer.




2. Choose your printer.



3. Once connected successfully, the "x" on the printer icon will disappear, and the text will change to "Connect".



4. Tap the printer icon in the top right corner to check the connection status or disconnect the printer.



Ezlabel Bluetooth Connection

INSTRUCTIONS



Scan the QR code below using an Android or iOS device to download the Relabel APP.




Ezlabel

1. Open “EZLabel” APP, tap the printer icon in the top right corner to connect the printer.


2. Choose Bluetooth




3. Choose Your Printer



4. Once connected successfully, the "x" on the printer icon will disappear, and the text will change to the printer model name.





www.3nstar.com



3nstar