

PC INDUSTRIAL MINI PC PC087

User's Manual



NOTICE














First of all, thank you for Purchasing Mini Computer.

We strongly recommend that you read this manual carefully before using this product, which will bring great convenience to your use. We will not take any responsibility if you operate the computer before you read the instruction. At the same time, in order to improve the equipment performance, there might be some small alignment, which may lead to inconsistencies in the specification, it will not affect the use of your product.

PRECAUTIONS

- Do not place any object on the product or block the heat emission hole.
- Place the power cord in a place where no one can step on, and do not place any items on the power line.
- Do not force the power plug into the slot, if you encounter a larger resistance, please confirm the correct direction of the plug of the slot.
- Ensure the use of AC power supply in its safe range of 100-240V, thus the product can be linked to the power outlet.
- Never pour any liquid into the equipment, so as not to damage the equipment or lead to electric shock.
- Attention to please, do not interrupt the power supply when the product is updated
- Before cleaning the product, please turn off the machine and unplug the power adapter.
- Avoid using in dusty or dirty environment, so as to avoid the system failure.
- Unexpected power outages can damage the product, please avoid connecting the product to a power outlet that has the potential to cut off the power supply.
- Any of the following circumstances, please check the product by the maintenance staff: power line or plug is damaged; the liquid penetration to the equipment; products exposed to moisture; products can not be normally operated, or in accordance with your product manuals are still unable to make this product operation; products manuals are still unable to make this product operation; products have fallen and damaged; products have obvious signs of damage.
- Please avoid making some small pieces of paper, small screws and other items in contact with the product connector, such as the location of the vacancy, so as to avoid short circuit conditions.

INSTALLATION PROCEDURE

					
SSD slot		RAM slot		WIFI module	
H1 SERIES 					
		① open mini pc box	② HDD fixed	③ HDD cable connect	
H3 SERIES 					
		① open mini pc box	② HDD fixed	③ HDD cable connect	
H5 SERIES 					
		① open mini pc box	② HDD fixed	③ HDD cable connect	

WARRANTY CREDENTIALS:**1. Valid warranty credentials:**

- (1). Warranty card
 - (2). Valid purchase invoice
 - (3). Product bar code
 - (4). Legal purchase and sale contract/packing
- (1) The product warranty card must include: seller name, product model, product number, date of purchase.
- (2). The effective purchase invoice with the normal commercial invoice stamp tax.
- (3). Product bar code: clear and complete, no modification.
- (4). The legitimate purchase and sale of the contract, the provisions of the warranty provisions of the product packaging are valid, customers need to show it initiative.

WARRANTY PERIOD:**(1) Warranty times begin:**

- Date of purchasing on the valid purchase card
 - Confirmed date of purchasing invoice
 - Cant provide the above two warranty credentials
 - Date on the legal purchase and sale contract
- (2) Maintenance or replacement of the product, the quality assurance is three months, if the original warranty period remaining more than three months, the original warranty period shall be.
- (3) In addition to the product bar code calculated warranty period, when multiple warranty credentials valid at the same time, in accordance with the most conducive to the interest of customers for warranty.

ATTENTION:

The following situation causing product failure is not in the free warranty:

- (1) Be out of the warranty time
- (2) The user has the responsibility to provide a valid warranty credential unable to provide a valid warranty certificate or product bar code damaged is not guaranteed.
- (3) With the product bar code as the strating time for the warranty, the maintenance by non designed agencies is invalid.
- (4) The warranty credential is not in conformity with the product of when there is a false record.
- (5) Failure to dismantle, repair or modify the product without authorization from the

manufacturer.

(6) Failure by abnormal transportation, loading and unloading, use, maintenance, custody and other causes, such as: lightning, over flow, water, etc.

(7) Failure by force majeure.

(8) The warranty and service should be within 5 years after the product stop production.

When the user found that the purchase of the equipment product failure, please hold the product warranty card and dealer or distributor contact request technical services.

WARRANTY CARD


Product model: Date of purchase:

Customer name: Product service hotline:

Date of inspection qualified: Quality inspector:

Customer feedback product's problem:

Maintenance results (filled by maintenance man):



www.3nstar.com



3nstar