

P4

POS TERMINAL

User's Manual



TABLE OF CONTENTS

• Product Overview	4
• Box Content	4
• Product Design Specifications	5
• Wiring Installation	6
• Screen Wiring Installation	7



DISCLAIMER

Please be aware that the interface and appearance of the all-in-one shown in this picture may differ depending on the specific model you have purchased. For precise information regarding the transmission interface and appearance, we advise consulting the actual product or reaching out to your supplier directly.


PRODUCT OVERVIEW

The 3nStar P4 is a high-performance all-in-one terminal designed for retail, hospitality, and commercial applications. It combines a sleek, modern design with powerful processing capabilities to deliver a stable, efficient, and cost-effective POS solution.


Key features include:

1. **Multiple Mounting Options:** Supports desktop, wall, and pole mounting to adapt to different installation environments.
2. **Flexible I/O Interfaces:** Equipped with versatile I/O ports to support a variety of external devices such as scanners, printers, cash drawers, and customer displays.
3. **High-Performance Processor:** Delivers fast and stable operation, even in demanding usage scenarios.
4. **Fanless, Silent Operation:** Designed with a fanless structure for quiet performance and reduced maintenance.
5. **Tool-Free Design:** Allows for quick assembly and maintenance with minimal effort.
6. The P4 is ideal for any setting where style, reliability, and flexibility are required.


BOX CONTENT

ITEM	QUANTITY	
P4 AIO Terminal	1	
Power Cable	1	
Power Adapter	1	
User Manual	1	

PRODUCT DESIGN SPECIFICATIONS



PORT NAME	FUNCTION
Display-2	External display port
USB 3.0 (x2)	High-speed USB for peripherals (scanner, printer, etc.)
12V DC	Power input connector
LAN	Ethernet connection (RJ45)
USB 2.0	Standard USB port for peripheral use
LINE OUT	Audio output



PORT NAME	FUNCTION	PORT NAME	FUNCTION
Cash Drawer	RJ11 cash drawer interface	USB	Peripheral connections (x2)
USB	Peripheral connections (x2)	COM2	RS232 Serial Ports
COM2 / COM3	RJ50 Serial Ports		

WIRING INSTALLATION:

Follow these steps to properly connect your **P4** terminal and peripherals




Figure 1	Adjust the main unit and base to the desired viewing angle.
Figure 2	Open the interface cover plate.
Figure 3	Secure the base by tightening the thumb screw clockwise.
Figure 4	Pass the power DC plug through the opening and connect it to the main unit's power input port.
Figure 5	Connect the power adapter to the power cord, then plug it into a wall outlet.
Figure 6	Press the power button once to turn on the device. The unit is now ready for normal operation.

SCREEN WIRING INSTALLATION:

If your setup includes a second screen (such as a customer-facing display), follow these steps to install it correctly:




Figure 1	Locate the two release points on the decorative cover.
Figure 2	Use your fingers or a small tool to gently pry open and remove the cover.
Figure 3	Align the secondary screen with the mounting bracket. Secure the screen in place using the provided flat-head screws.

Powering On and Off

Power On:


While the device is powered off, press and hold the power button for one second to turn it on.

Restart:

While the device is running, click the **Start** menu at the bottom-left corner of the screen and select **Restart**.

Power Off:

To shut down the system, click the **Start** menu and select **Shut Down**.



www.3nstar.com

  | 3nstar